

Basic & Kernal Jumper Settings

ROM Image #	A13	A14	A15
1	Left	Left	Left
2	Right	Left	Left
3	Left	Right	Left
4	Right	Right	Left
5	Left	Left	Right
6	Right	Left	Right
7	Left	Right	Right
8	Right	Right	Right

Character Jumper Settings

ROM Image #	A12	A13	A14	A15
1	Up	Up	Up	Up
2	Down	Up	Up	Up
3	Up	Down	Up	Up
4	Down	Down	Up	Up
5	Up	Up	Down	Up
6	Down	Up	Down	Up
7	Up	Down	Down	Up
8	Down	Down	Down	Up
9	Up	Up	Up	Down
10	Down	Up	Up	Down
11	Up	Down	Up	Down
12	Down	Down	Up	Down
13	Up	Up	Down	Down
14	Down	Up	Down	Down
15	Up	Down	Down	Down
16	Down	Down	Down	Down